
CMF Surgery



# Angulus 2


Angled Screwdriver





### Table of Contents

|                               | Pages   |
|-------------------------------|---------|
| Feature, Function and Benefit | 6 - 9   |
| Step by Step to Optimal Care  | 10 - 19 |
| Assembly                      | 12 - 15 |
| Surgical Technique            | 16 - 19 |
| System Components             | 20 - 21 |
| Storage                       | 22      |
| Recommended Set Configuration | 23      |



# Angulus 2


### Angled Screwdriver

The angled screwdriver rounds off our product portfolio for transoral osteosynthesis in hard to reach regions of the jaw.

It is particularly well suited for osteosynthesis at the mandibular angle and ramus up to the condylar process.

Along with osteosynthesis plates and other instruments, especially developed for this indication, we provide complete one-stop solutions for this demanding anatomical region.

# Feature, Function and Benefit




In osteosynthesis of the mandibular ramus and condyle transoral access has become ever more important. Miniaturized instruments especially developed for this indication are indispensable.

The angled screwdriver is a useful tool, allowing the surgeon to implant screws, plates, and distractors under the most constricted spatial conditions and without visible scarring.

#### Angulus2

#### New design




#### Feature


#### Benefit

- Low profile (8 mm) head and slim shaft geometry
- Centered tool mount
- Best view possible in site
- Perfect transmission of force without tool canting
   Suitable on both sides

#### **Function**




- Standardized INTRA coupling (ISO 3964)
- Suitable for numerous motor systems of various manufacturers
- For motor driven pre-drilling




- Gear ratio 1.75: 1 Universal coupling for turning handle
- For easier manual screw down

#### Screw/implant holding device



- Optional adaptable holding device for screws up to 2.5 mm in diameter and corresponding plates or distractors
- Allows one-handed insertion of screws, plates, and distractors
- After use, the holding device can be pushed back and turned sideways, thus giving the best view possible in the site

#### Tool change



- Quick release chuck
- Rapid intraoperative tool change in just two steps without additional measures

# Feature, Function and Benefit





Specially configured storage trays help sustain the value of the angled screwdriver. They ensure clear and gentle storage and facilitate the appropriate sterilization of all system components.

#### Angulus2

#### Disassembly



#### Feature

#### Benefit

- Plug, screw and bayonet lock
- Toolless disassembly in just a few steps
- Rapid delivery for postoperative processing Easy cleaning and disinfection

#### Tools





- Low installed height
- Good handling Best view possible in site

Color coding


Quick and safe selection

of appropriate tool

■ Form-fit

 Secure tool grip in head of angled screwdriver

#### Small parts storage






Compact design

- Made for wire basket
- Separate color coded compartments for twist drills and blades
- Clear tool storage
- Diameter and depth meter for twist drill
- Controlled tool selection and storage

#### Wire basket



Standard dimensions: L 255 x W 245 x H 50 mm

■ Lid

- Silicone and PPSU storage elements
- Made for standardized half-size containers
- Clearly arranged storage for two angled screwdrivers, one turning handle, one screw holding device and small parts storage
- Protected against spilling

# Step by Step to Optimal Care

### Use

The angled screwdriver Angulus 2 is suited for transoral osteosynthesis at the mandibular body and ramus.





## Handling and Surgical Technique

### Assembly

Pages 12-15




#### Surgical Technique

Exemplified by implantation of a "Rhombic" 3D Condylar Plate

Pages 16-19






#### 1. Inserting the head


Slide the head 1 into the sheath 2 until fully seated.

Observe the icons and twist from ○ "open" to ● "locked".

#### Note:


During assembly verify that the EN (serial numbers) of the components match. Especially when using several angled screwdrivers.





### 2. Mounting the shaft


Slide the shaft 3 into the sheath 2 and tighten in clockwise direction.



#### 3. Attaching screw/implant holding device

Slide the screw holding device 4 over the sheath until it engages with an audible click.

Check the position and click-fit the clip 5 of the screw holding device



#### 4. Clamping and unclamping the tool

All the twist drills or corresponding screwdriver blades listed on page 21 can be used with the angled screwdriver. After opening the tension clamp <sup>(6)</sup>, the desired tool can be inserted and then locked securely by pushing back into the initial position.

After the tool has been inserted, the appropriate drive is attached:


- Twist drills: automatic (motor)
- Screws: manual (turning handle)

The tool is removed by opening the tension clamp as described above.

#### Tip:

Using a second Angulus 2 allows rapid intraoperative changeover between pre-drilling and screw insertion.







#### Preoperative planning

The x-ray shows a typical medially dislocated condylar process fracture, Spiessl and Schroll type II.




#### 1. Predrilling


As condylar process fractures are nearly always dislocated, the surgeon will generally first place the osteosynthesis screw which is closest to the fracture gap of the fractured condyle and therefore easy to access. For pre-drilling, mount the angled screwdriver on the motor and pre-drill with a maximum motor speed of 4,375 rpm.

#### Note:

Since the angled screwdriver has a gear ratio of 1.75:1, the motor speed of 4,375 rpm results in a speed of 2,500 rpm for the drill bit.







#### 2. Clamping screw and plate

Pick up the screw and clip the corresponding plate hole into the screw. Then push the screw holding device, which can optionally also be used as plate holding device, forward to fixate the implants.

#### 3. Insertion of the implants

To implant the first screw, the turning handle is first attached to the angled screwdriver. Once the screw has found purchase in the bone, the screw and plate holding device is retracted. Then the implants can be pre-fixated.







for Angulus 2





#### 4. Pre-drilling of additional screw holes

To achieve the desired fracture position, the drill holes in the gliding holes of the plate are set as caudally as possible.

Once the surgeon has convinced himself/herself of the correct anatomical position of the condyle or the cranial fragment, then this position can be secured successively with further screws in the caudal, intact region of the jaw. Due to the special gliding hole geometry of the plate, there are still 2.5 mm of glide path available for any further corrections if necessary. After setting the desired fracture reduction, the screws are tightened firmly in the gliding holes.

#### 5. Placement of the final screw

The final osteosynthesis screw is placed as soon as the fracture has been sufficiently repositioned. This screw cancels the gliding hole effect.







Angulus 2 with turning handle and screw holding device

Screwdriver blade for Angulus 2



Source: Prof. Dr. Dr. Günter Lauer, University Clinic Dresden

#### Postoperative control

The postoperative x-ray shows the repositioned condyle process and the correct position of the "Rhombic" 3D condylar plate which was implanted safely and effectively using the Angulus 2.

## Angled Screwdriver Angulus 2 System components



50-990-00-07 Angled screwdriver, complete with turning handle and screw holding device





50-990-01-07 Angled screwdriver without turning handle and screw holding device





50-990-05-07 Turning handle (spare part)








50-990-06-07 Screw holding device (spare part)







#### Twist Drills



#### Screwdriver Blades

| St (1) (1) |   | for screws    |          | Item no.     |  |
|------------|---|---------------|----------|--------------|--|
|            |   | Ø 1.5 mm      | •        |              |  |
|            |   | maxDrive®     |          | 50-991-15-07 |  |
| n.         | n | Centre Drive® |          | 50-992-15-07 |  |
| 1/1        | 1 | Cross Drive   | <b>+</b> | 50-993-15-07 |  |
|            |   | Ø 2.0/2.3 mm  | • •      |              |  |
|            |   | maxDrive®     |          | 50-991-20-07 |  |
|            |   | Centre Drive® |          | 50-992-20-07 |  |
|            |   | Cross Drive   | $\oplus$ | 50-993-20-07 |  |

# Angled Screwdriver Angulus 2 Storage



50-990-40-04
Wire basket for angled
screwdriver Angulus2
including lid and holding elements
(without contents)



50-990-41-04

Small parts storage

for twist drills and screwdriver blades
(without contents)



# Angulus 2 Recommended set configuration\*

(\* for use with maxDrive® screws 1.5 mm and 2.0 mm)

| Angled screwdri                 | iver  |         |  |  |  |
|---------------------------------|---|---------|--|--|--|
| 50-990-00-07                    | Angled screwdriver Angulus 2, complete            | 1 unit  |  |  |  |
| 50-990-01-07                    | Angled screwdriver Angulus 2, only                | 1 unit  |  |  |  |
|                                 |   |         |  |  |  |
| Twist drill for screws Ø 1.5 mm |   |         |  |  |  |
| 50-995-05-07                    | Twist drill for Angulus 2 WSD, 1.1 x 5 mm         | 2 units |  |  |  |
| 50-995-07-07                    | Twist drill for Angulus 2 WSD, 1.1 x 7 mm         | 2 units |  |  |  |
| 50-995-17-07                    | Twist drill for Angulus 2 WSD, 1.1 x 17 mm        | 1 unit  |  |  |  |
| Twist drill for screws Ø 2.0 mm |   |         |  |  |  |
| 50-996-05-07                    | Twist drill for Angulus 2 WSD, 1.5 x 5 mm         | 4 units |  |  |  |
| 50-996-07-07                    | Twist drill for Angulus 2 WSD, 1.5 x 7 mm         | 4 units |  |  |  |
| 50-996-09-07                    | Twist drill for Angulus 2 WSD, 1.5 x 9 mm         | 2 units |  |  |  |
| 50-996-13-07                    | Twist drill for Angulus 2 WSD, 1.5 x 13 mm        | 1 unit  |  |  |  |
| 50-996-17-07                    | Twist drill for Angulus 2 WSD, 1.5 x 17 mm        | 1 unit  |  |  |  |
|                                 |   |         |  |  |  |
| Screwdriver bla                 | des   |         |  |  |  |
| 50-991-15-07                    | Screwdriver blade maxDrive® 1.5 for Angulus 2 WSD | 2 units |  |  |  |
| 50-991-20-07                    | Screwdriver blade maxDrive® 2.0 for Angulus 2 WSD | 2 units |  |  |  |
|                                 |   |         |  |  |  |
| Storage                         |   |         |  |  |  |
| 50-990-41-04                    | Small parts storage for Angulus 2 WSD             | 1 unit  |  |  |  |
| 50-990-40-04                    | Wire basket for Angulus 2 WSD                     | 1 unit  |  |  |  |

#### **KLS Martin Group**

KLS Martin France SARL 68200 Mulhouse · France Tel. +33 3 8951 3150 france@klsmartin.com

Martin Italia S.r.I. 20864 Agrate Brianza (MB) · Italy Tel. +39 039 605 67 31 italia@klsmartin.com

Martin Nederland/Marned B.V. 1270 AG Huizen · The Netherlands Tel. +31 35 523 45 38 nederland@klsmartin.com KLS Martin UK Ltd.
Reading RG1 3EU · United Kingdom
Tel. +44 1189 000 570
uk@klsmartin.com

Nippon Martin K.K. Tokyo 113-0024 · Japan Tel. +81 3 3814 1431 nippon@klsmartin.com

KLS Martin L.P.
Jacksonville, FI 32246 · USA
Tel. +1 904 641 77 46
usa@klsmartin.com

KLS Martin do Brasil Ltda. CEP 04.531-011 São Paulo · Brazil Tel.: +55 11 3554 2299 brazil@klsmartin.com

KLS Martin Australia Pty Limited Artarmon NSW 2064 · Australia Tel.: +61 2 9439 5316 australia@klsmartin.com

KLS Martin SE Asia Sdn. Bhd. 14100 Simpang Ampat, Penang · Malaysia Tel.: +604 505 7838 malaysia@klsmartin.com Gebrüder Martin GmbH & Co. KG Representative Office 121471 Moscow · Russia Tel. +7 499 792-76-19 russia@klsmartin.com

Gebrüder Martin GmbH & Co. KG Representative Office 201203 Shanghai · China Tel. +86 21 5820 6251 china@klsmartin.com

Gebrüder Martin GmbH & Co. KG Representative Office Dubai · United Arab Emirates Tel. +971 4 454 16 55 middleeast@klsmartin.com

Gebrüder Martin GmbH & Co. KG A company of the KLS Martin Group KLS Martin Platz  $1 \cdot 78532$  Tuttlingen  $\cdot$  Germany Postfach  $60 \cdot 78501$  Tuttlingen  $\cdot$  Germany Tel. +49 7461 706-0  $\cdot$  Fax +49 7461 706-193 info@klsmartin.com  $\cdot$  www.klsmartin.com